

FEATURES

- Allows computer and appropriate software to control Z-Wave RF devices through an RS232 port.
- Complete with RS232 connector cable and 9V power adaptor.

PRODUCT DESCRIPTION

The **ZCS201 RS232 Interface** allows you to communicate from any RS232 port to control Z-Wave enabled products.

Protocol information on bottom of device.

ACT does not provide any computer software for this product.

This product is intended to be used with third party software developed using the Z-Wave dll. The Z-wave dll is available in the Z-Wave™ Developers Kit.

Based on Version 2.24 of the Z-Wave™ API Library

Protocol information available in Version 4.24 of Z-Wave™ Developers Kit

HomePro wireless radio frequency products utilize Z-Wave™ technology to communicate and inter-operate, and are compatible with other Z-Wave™ enabled products.

ZCS201 has non skid feet for placement on horizontal surfaces.
Includes External Power Supply.



RS232 (Equipped with DB-9 Connector)



Power Supply Included

ORDERING INFORMATION

Specify: **ZCS201** - RS232 to Z-Wave Interface, with 230V Power Supply

SPECIFICATIONS

Electrical

Power	External Power Supply included - 230 VAC to 9 VDC Power Supply (200mA) with 2.1mm power plug, center (+) positive.
Signal (Frequency)	868.42 MHz
Range	Up to 30 meters (line of sight) between the ZCS201 Interface and the closest Z-Wave enabled product.

Mechanical

Dimensions	13.98cm W x 10.17cm D x 3.49cm H (5.505" W x 4.005" D x 1.375" H)
Weight	Approx. 227 grams (8 oz.)
User Interface	Computer and appropriate software

Environmental

Operating Temperature Range	0-40° C (32-105° F) For Indoor Use Only
-----------------------------	---

Specifications may change without notice to improve product performance.

INSTALLATION INSTRUCTIONS:

Connect the ZCS201 to an RS232 port on the computer.

Connect the provided power supply to the ZCS201 (required for proper operation).

Make sure the antenna is straightened to a vertical position for best possible results.

Insert the third party software CD into the computer and follow the instructions on the screen.

Follow instructions contained in the third party manual or installation documents provided on the CD.

Note: This product does not support "sleep" mode or "power saver" mode on computers. This insures that the controller will always maintain communication with Z-Wave enable devices.